



SECTIONAL VIEW

Form 1




Part List

01	Volute
13	Column Pipe
16	Discharge Pipe
19	Motor Stool
20	Impeller
41	Thrust Bearing
45	Intermediate Bearing
50	Stuffing Box
60	Shaft
67	Bearing Sleeve
200	Bearing
500	Electrical Motor
550	Grease Pump
600	Coupling



SECTIONAL VIEW

Form 2



Part List

01	Volute
02	Suction Mouth
05	Wear Ring
11	Support Foot
20	Impeller
30	Bearing Housing
50	Stuffing Box
53	Gland
55	Lantern Ring
60	Shaft
65	Impeller Nut
70	Shaft Sleeve
200	Bearing






SECTIONAL VIEW



Form 3



Part List

01	Volute
02	Suction Bendh
05	Wear Ring
16	Motor Stool
20	Impeller
30	Bearing Housing
31	Bearing Housing
50	Stuffing Box
53	Gland
55	Lantern Ring
60	Shaft
70	Shaft Sleeve
180	Coupling (CAP-VM)
200	Bearing (73....)
201	Bearing (NU....)
250	Mechanical Seal
390	Cardan Shaft (CAP-VS)
391	Intermadiate Bearing (CAP-VS)
392	Safety Guard
500	Electric Motor

